




IoT Alarm System with Bed Presence Detection

Presented by:
Luca Torzi & Lorenzo Venerandi



Features

- The alarm is **automatically triggered and stopped**
- Check if the user fall asleep again
- **Web UI**
- **Manage the alarms**
- **Data forecasting**

Device: esp8266-lore

Average request time 309 ms

Sampling rate

Update

Sensor threshold

Update


Device city

Update

Trigger alarm


Stop alarm

Start device calibration



Architecture Components



- Smart alarm device



ESP
Firmware



- MQTT broker
- InfluxDB
- Data Proxy Server
- Data Analysis Server
- Telegram Bot



Kubernetes



Docker
Container

Deployment done
using kubernetes



Pod



Service



Volume



ConfigMap



Secret



Helm




Hardware Components

Main components

- ESP8266
- Pressure mat sensor
- Speaker

Main libraries used


- PubSubClient
- ESP8266Wifi
- ESP8266HttpClient
- ESP8266Audio



MQTT Broker



- **EMQX** is a versatile and extensible platform
- Supports multiple communication protocols
- Guarantees the communication to the actuator




Data Proxy Server

- Manage the devices via HTTP requests
 - `/api/devices`
 - `/api/sampling_rate`
 - `/api/city`
- Manage the alarms via HTTP requests
 - `/api/alarms`
 - `/api/add_alarm`
 - `/api/remove_alarm`
 - `/api/trigger_alarm`
 - `/api/stop_alarm`



Data Proxy Server

- manage the devices via MQTT messages to `/devices/device_id`
 - `sampling_rate [value]`
 - `trigger_alarm [int]`
 - `stop_alarm`
- Receive data from the device via HTTP requests
 - `/api/sensor_data`



Data collection pipeline

InfluxDB

- Open-source time-series database
- Optimized for managing large volumes of data



Grafana



- Dashboard to visualize the pressure sensor data stored in InfluxDB



Data Analysis Server

Calibration of the device

- `/analyze/calibration`
- `/analyze/get_weights`
- `/analyze/set_threshold`




Data Analysis Server

Analyze the data collected

- `/analyze/compute_sleep_time_for_day`
- `/analyze/sleeping`
- `/analyze/check_sleep`

Day	Accuracy	Precision	Recall	F1-Score
Day 1	0.59	0.99	0.36	0.53
Day 2	0.89	1.0	0.53	0.96
Day 3	0.57	0.87	0.39	0.54
Day 4	0.63	0.63	0.59	0.61





Data Analysis Server

Forecasting

- `/analyze/forecast`

Trained using the values of the 4 previous days, augmented by 10 times.



Telegram Bot





Commands


- /help
- /get_devices
- /get_alarms
- /add_alarm
- /remove_alarm
- /update_alarm
- /trigger_alarm
- /stop_alarm



Use Case: Trigger Alarm



Web Application - Login



Welcome to Smart Alarm Manager!

Add your credentials


Username

Password


☒ Remember me [Forgot Password?](#)

[Don't have an account? Register](#)


Web Application - Devices



Web Application - Alarms



Web Application - Alarms





THANKS FOR
THE ATTENTION